


## Measuring Guide for **Roman blinds.**

Measuring for your stunning new blind with 1Clickblinds is a straightforward process. Just follow our step-by-step guide, ensuring to double-check your measurements as you progress, and be on the lookout for helpful tips to streamline the process. Here is a convenient guide specifically for measuring Roman blinds.

### **Recess fitting**

If you want your blind to fit inside the window recess.



Depth needed for Roman blinds = 45mm


This is the measurement you should take if you desire your blind to be accommodated inside the window recess. Measure the complete width and height of the recess, leaving deductions to our experts. This ensures you receive a blind tailored to fit seamlessly inside the recess.

- **Measure in 3 places for both the width and the drop, use the smallest measurements you've taken**
- **Refrain from making any deductions; we will handle that for you.**
- **Opt for a metal tape measure; cloth ones may stretch and provide inaccurate measurements.**

**Useful Tip:** Double-check the depth of your recess (refer to the recess checking tips on the opposite side) – ensure it is deep enough to accommodate the blind. Also, check for any obstructions such as handles or ventilation.

### **Exact fitting**

If you want your blind to fit outside the window recess.



- **Measure the recess as demonstrated on the opposite side before adding extra height and width to each side. We will craft your blind precisely to that specified size without any deductions.**
- **If you aim to minimize light infiltration, we recommend adding a minimum of 50mm on each side and 70mm to the top.**
- **Exercise caution at the bottom of the blind to avoid contact with protruding objects like sills or radiators.**

**Useful Tip:** Are you replacing an existing blind, similar to the one you currently have? Measure the blind, including the fittings (refer to blind measuring tips on the opposite side), and choose the Exact fitting option. We will craft a new blind for you in the same size.

## Non-standard windows

Fitting inside a part-tiled recess (also for picture rails, skirting boards).




Measure between the tiles to ensure the blind will fit

Is there tiling along the sides of your window recess? These tiles may likely reduce the available width compared to a standard recess. Measure the width between the tiles to determine your overall width. Employ this method if there is a skirting board, picture rail, or any other obstruction inside the recess.

## Bay windows, Half-bays & L-shaped windows

These specific window styles require a more detailed approach for measuring Vertical blinds. To assist you in this process, we've developed dedicated measuring guides for each style. Visit [www.1clickblinds.co.uk](http://www.1clickblinds.co.uk) for comprehensive guidance.


### Angled Bay windows



Measuring guide for Angled Bay windows is available at [www.1clickblinds.co.uk/pages/how-to-measure-for-baywindow-blinds](http://www.1clickblinds.co.uk/pages/how-to-measure-for-baywindow-blinds).

Please note that the same guide can be utilized for Angled Half-bay windows as well.

### Square Bay and L-shaped windows



A measuring guide for Square Bay and L-shaped windows is accessible at: [www.1clickblinds.co.uk/pages/how-to-measure-for-baywindow-blinds](http://www.1clickblinds.co.uk/pages/how-to-measure-for-baywindow-blinds).

Once you have noted your measurements, enter the sizes into [www.1clickblinds.co.uk/collections/roman-blinds](http://www.1clickblinds.co.uk/collections/roman-blinds) and choose your fitting option. We will make your new blind to your sizes and send them out to you ready to fit.

## Measuring Guide for **Roman blinds** in an Angled Bay window

*Measuring for your exquisite new blind with 1Clickblinds is a straightforward process. Just follow our step-by-step guide, ensuring to double-check your measurements as you progress, and be on the lookout for helpful tips to streamline the process. Below is a convenient guide specifically for measuring Roman blinds in an Angled Bay window.*


### Step 1

Before commencing with the measurements, determine the placement of the blinds – allocate 50mm for our Roman blinds headrail. Be mindful of potential obstacles such as window handles or air vents. If present, add these dimensions to the depth of your brackets to establish reference measurement point X.

**In addition to your measuring tape, gather two pieces of paper or card (A4 or A5 size is suitable), a pencil, and a ruler.**


### Step 2

Position your two paper pieces side by side, as demonstrated, and mark the X measurement that was taken before on both sheets.




### Step 3

Position the paper against the window frame on the sill. Slide the paper along the sill until the two marks meet.




### Step 4

Lightly use your pencil to mark the window sill where the paper edge meets the frame. Repeat this process for other angles in the frame.



## Step 5

Measure the distance between the marks to determine the width of the blind.



**Useful Tip:** Leave the pencil marks untouched – these will be a useful guide for fitting your new blind.

## Step 6

To measure your drop, take a measurement from the top of the blind to where you want it to rest, typically the window sill. Keep in mind that the headrail will be included in the drop measurement.

Once you have noted your measurements, enter the sizes into [www.iclickblinds.co.uk/collections/roman-blinds](http://www.iclickblinds.co.uk/collections/roman-blinds) and choose the Exact fitting option. We will make your new blind to your sizes without deductions and send them out to you ready to fit.

Measuring Guide for

# Roman blinds

## in a Square Angled/ Box Bay window

*Measuring for your exquisite new blind with 1Clickblinds is a straightforward process. Just follow our step-by-step guide, ensuring to double-check your measurements as you progress, and be on the lookout for helpful tips to save time. Below is a handy guide specifically for measuring Roman blinds in a Square Angled/Box Bay window.*

### Step 1 – Measuring the width

Roman blinds are the professional's choice for a Square Angled/Box Bay window. Measure the width of side blinds from recess edge into the corner then deduct the bracket allowance of 45mm. Measure from corner to corner and deduct two bracket (90mm) allowances for the front blind. Order all three blinds as Exact fitting.



### Step 2 – Measuring the drop

Measure the drop as usual – in three places. Be mindful of how you are installing the blinds to know where the top is for measuring down from.

Note that the headrail is included in the drop measurements. Ensure you have a flat space of 30mm to securely mount the brackets.

*Once you have noted your measurements, enter the sizes into [www.1clickblinds.co.uk/collections/roman-blinds](http://www.1clickblinds.co.uk/collections/roman-blinds) and choose the Exact fitting option. We will make your new blind to your sizes without deductions and send them out to you ready to fit.*